

1-800-814-4053

matko
 ELECTRONIC DISPLAYS

Section 5: Option Summary

To enter into the options hold the **LEFT** button during power up. At the end of the countdown the display will display "OPTION". Once in options, **LEFT** will cycle through the option numbers 0 through 20. The **RIGHT** button will toggle between On/Off for some options and will enter into an advanced menu for more complicated options. See specific options in Section 6 for more advanced option descriptions. Pressing **LEARN** at any time will save the settings and reset the display. To restore to factory default, press both the **LEFT** and **RIGHT** button simultaneously.

#	Name	Description for "ON" Value	
0	Reset	off	Resets all settings to factory defaults
1	Version	off	Displays the current software version
2	Toledo / Fairbanks	off	Decodes Toledo / Fairbanks status bytes
3	Timeout Length	off	Maximum time allowed between data transmissions Default = 5 seconds
4	On Demand	off	Updates display when a Print button is pressed Turn ON if transmissions are more than 2 sec. apart
5	No Data	off	Set to display "nodata", to blank or to retain the last value when not receiving data
6	Fixed Decimal	off	Sets a fixed decimal point position
7	No Count Down	off	Does not count down on startup
8	No 0 Suppression	off	Does not suppress leading 0's
9	Alpha	off	Will display alpha and numeric characters
10	Mirror	off	Displays data to be seen in a rearview mirror
11	Addressable	off	Makes the display addressable
12	No Auto Shift	off	Disable auto shifting while learning
13	Shift	2 -	Set or view the shift value
14	Baud Rate	6 -	Set or view the baud rate
15	End Character	13 -	Set or view the end character
16	Minimum Weight	off	Sets the minimum weight to display
17	Maximum Weight	off	Sets the maximum weight to display
18	Blank Out Character 1	off	Sets a character to cause the scoreboard to blank
19	Blank Out Character 2	off	Sets a character to cause the scoreboard to blank
20	Blank Out Character 3	off	Sets a character to cause the scoreboard to blank
21	Red Stoplight	off	See Section 7 2 82 -
22	Green Stoplight	off	See Section 7 1 2 71 -
23	Toledo High Speed	off	Display annunciators for grams and ounces
24	Fairbanks Addressable	off	Addressable for Fairbanks 40-41
25	Fixed Annunciators	off	Choose the LB/KB and GR/NT annunciators indicated regardless of data stream
26	Demo Mode	off	Cycle through different weights as a demo
27	Intensity	off	Set the intensity low (off) or high (on)

matko